

Trash Car Train Data Set Preparation

Trash Car Train Data Set Preparation

[Introduction](#)

[Image prepare](#)

[Label annotation](#)

[Train](#)

[Reference](#)

Introduction

There has 4 classes and 5 instance in the `trash_c4_i5` dataset in total. This booklet is used to guide image taking and labeling to create `trash_c4_i5` dataset.

Image prepare

1. Number

We need 100 images per instance. 50 images on the green floor and 50 images on the mutative background.

2. Environment

1. Green floor images:

1. Multiple instances on the same images.
2. Simulate real environment.

2. Mutative background images: 3. Keep lighting strength changing. 4. Background changing. NO TWO SAME IMAGE.

3. Naming

Image should start at **001.jpg** and end at **100.jpg** the corresponding label should as same as images.

4. Files Level

```
trash_c4_i5
|-- data
|   |-- predefined_classes.txt
|   |-- trash_c4_i5.yaml
|-- images
|   |-- train
|       |-- 1.jpg
|       ...
|   |-- valid
|       |-- 1.jpg
|       ...
|-- labels
|   |-- train
|       |-- 1.txt
|       ...
|   |-- valid
|       |-- 1.txt
|       ...
```

5. Camera and Image Size

Use RGB camera which used in competition environment. And take the size of 640×480 .

Label annotation

[Label app](#): click to check and download.

The classes order is shown as below, DO NOT change this order.

```
bottle  
battery  
cup  
orange  
paper
```

The file is arranged as below:

1. The default order is predefined in the file `trash_c4_i5/data/predefined_classes.txt`.
2. The annotations target dir is `trash_c4_i5/labels/`.
3. The images are saved in dir `trash_c4_i5/images/`.

The name of annotation must be as same as image. Must choose the **yolo** style to label all the images.

The useful hotkeys:

Ctrl + u	Load all of the images from a directory
Ctrl + r	Change the default annotation target dir
Ctrl + s	Save
Ctrl + d	Copy the current label and rect box
Ctrl + Shift + d	Delete the current image
Space	Flag the current image as verified
w	Create a rect box
d	Next image
a	Previous image
del	Delete the selected rect box
Ctrl++	Zoom in
Ctrl--	Zoom out
↑ → ↓ ←	Keyboard arrows to move selected rect box

Train

you can train with `--img 1280` and/or `--rect`, though `--rect` is not recommended for best results. Which is trained as mosaics.

Reference

Image size

[1] <https://github.com/ultralytics/yolov5/issues/974>

[2] <https://github.com/ultralytics/yolov5/issues/700>

Multiple GPU:

[3] <https://github.com/ultralytics/yolov5/issues/475>